



C1Y-001



C1W-001



C1Y-002



C1W-002



C1Y-003



C1Y-004



C1W-003



C2Y-001



C2Y-002



C2Y-003



C2Y-004



C3Y-001



C3W-001



C3Y-002



C3W-002



C4Y-001



C4Y-002



C4Y-003



C4Y-004



C4Y-005

CONTROL STATION/按鈕開關盒

Model Designation :

型號說明

Holes 孔數	Part Number 編號	Ctrl. Station 防塵防水盒	Control Units Combination 按鈕組合				Accessories 配件*
			1	2	3	4	
1 Hole 1孔	C1Y 001	NB22 C1Y	NPB22 R11R A				
	C1Y 002	NB22 C1Y	NSS22 K211B				
	C1Y 003	NB22 C1Y	NPB22 I11R				EMO 02Y
	C1Y 004	NB22 C1Y	NPB22 J11R				EMO 04Y
	C1W 001	NB22 C1W	NLB22 D11G				
	C1W 002	NB22 C1W	NSS22 S211B				
	C1W 003	NB22 C1W	NNS22 S211G				
2 Holes 2孔	C2Y 001	NB22 C2Y	NSS22 S211B	NPB22 F11G			
	C2Y 002	NB22 C2Y	NLB22 F11GE	NLB22 F11RE			
	C2Y 003	NB22 C2Y	NLB22 F11GE	NLB22 T11RE			
	C2Y 004	NB22 C2Y	NPB22 F11G	NPB22 F11R			
3 Holes 3孔	C3Y 001	NB22 C3Y	NPB22 F11G	NPB22 F11G	NPB22 F11R		Symbol printing 印字
	C3Y 002	NB22 C3Y	NPB22 F11G	NPB22 F11R	NPB22 F11Y		
	C3W 001	NB22 C3W	NLB22 F11GE	NLB22 F11RE	NSS22 K211B		
	C3W 002	NB22 C3W	NLB22 F11GE	NLB22 F11RE	NPB22 R11R A		
4 Holes 4孔	C4Y 001	NB22 C4Y	NLD22 RE	NPB22 F11G	NPB22 F11R	NPB22 T11R	
	C4Y 002	NB22 C4Y	NLD22 RE	NPB22 F11G	NPB22 F11Y	NPB22 F11R	
	C4Y 003	NB22 C4Y	NPB22 F11G	NPB22 F11Y	NPB22 F11R	NSS22 S211B	
	C4Y 004	NB22 C4Y	NPB22 F11G	NPB22 F11Y	NPB22 F11R	NSS22 K211B	
	C4Y 005	NB22 C4Y	NLB22 F11GE	NLB22 F11RE	NLB22 F11YE	NPB22 R11R A	

* Note:

The accessories are include a. Standard Legend Code (NCU-61-xx, page 9), b. Padlock Cover (page 7), c. Transparent Boots (page 7), d. Shrouds (page 8)

附註

配件包括 a. 標示銘板 (NCU-61-XX, 第9頁) · b. 鎖扣蓋 (第7頁) · c. 保護套 (第7頁) · d. 誤觸控保護座 (第8頁)

